



888.00 Solvent Inkjet Fabric Transfer

888.00 is a printable fabric transfer media specifically designed for eco, mild/low, hot solvent inkjet printers. This thin flexible design will produce brilliant colorful images with a white background on black or dark colored fabrics. The transferred result provides an extremely “soft hand” and excellent wear ability. This transfer media is produced on a silicone paper release liner with controlled peel tension to reduce curl and make weeding easier.

In order to produce the thinnest material with the softest hand special care must be taken when transferring to fabric. Please check instruction sheet on page 2 for proper application and use of this new design.

Feature	Advantage	Benefit
Fade resistant	Color stays brilliant after multiple washings	Durable, long lasting image
Versatile and easy to use	Print - cut - apply process	Save production time
Ultra-Thin Design	“Soft Hand”	Customer Satisfaction
Ability to be contour cut	Easily produce correct size transfer needed	Save time and media

Basis Weight: 58 gsm (transfer only)
Caliper: 1.7 mil (transfer only)
Brightness: 90 (min)
Release Liner: Silicone Paper

Arkwright believes that the information set forth herein is reliable. The information is intended for use by persons having technical skill at their own discretion. Since conditions of use are outside of Arkwright's control, we make no warranties, expressed or implied, and assume no liability in connection with any use of this information.



APPLICATION INSTRUCTIONS

888.00 Solvent Inkjet Fabric Transfer

Items Needed:

Sharp Cutter Blade

Application Tape (RTape Conform or Polyester Hot Mask Transfer Product (preferred))

Heat Press designed for fabric with the ability to heat to 375°F

1) Pre-Heat Press to the following for different fabrics:

100% Cotton: 375°F

50%/50% Cotton Polyester Blend 375°F

Use FIRM Pressure

ALL Times 15-20 Seconds

** Always test fabric and transfer material for compatibility

2) Design image according to printer/cutter specifications.

3) Print Temperatures @ 30° - 35°C (86°-95°F)

4) Before Contour Cutting:

Ensure Blade is sharp

Test Area to ensure proper cut force

Thin media use less force

5) Contour cut image, weed unwanted area

6) Tape with RTape® Conform or a polyester hot mask transfer

DO not overlap tape, use continuous piece that will cover entire graphic to be transferred

Ensure tape is applied from center out leaving no air bubbles

7) Press fabric for 5 seconds on heat press

To Remove Moisture

8) Flip image tape side down on table

Carefully remove release liner at a sharp angle to ensure transfer media does not stretch

9) Apply transfer onto fabric in desired location. PRESS for 15 seconds

10) Allow fabric and transfer to COOL completely

11) Remove transfer tape at a sharp angle not stretching transfer

12) WASH: Inside out, delicate mode

Arkwright believes that the information set forth herein is reliable. The information is intended for use by persons having technical skill at their own discretion. Since conditions of use are outside of Arkwright's control, we make no warranties, expressed or implied, and assume no liability in connection with any use of this information.